


AB-6PD/6PDH

Exploded View



Parts List

NO.9

Index No.	Parts No.	Description	No. Req'd	Index No.	Parts No.	Description	No. Req'd
1	1580001	Motor Housing	1	31	1530015	Hammer	2
2	0880020	Screw	2	32	0840020	Pin	2
3	0810034	Spring	2	33	1530017	Anvil Shank	1
4	1570009	Throttle Valve	2	34	1530018	Anvil Shank Bushing	1
5	0850041	"O"Ring	2	35	0800013	Washer	1
6	1570004	Reverse Valve	2	36	1530019	Housing Bushing	1
7	0840034	Throttle Valve Pin	2	37	1580003	Clutch Housing	1
8	0840010	Pin	1	38	0800014	Washer	3
9	1570002	Trigger	1	39	0880013	Screw	3
10	0880021	Screw	4	40	0810031	Circlet	2
11	1570006	Decorative Plate	1	41	0800025	Washer	2
12	1550003	Air Strainer Assembly	1	42	0810029	Spring	1
13	0800011	Washer	1	43	1530021	Block Sleeve	1
14	1800026	Intake valve core group	1	44	0870007	Steel Ball	1
15	0840156	Spring Pin	2				
16	0860001	Bearing	1	AB-6PDH			
17	1530008	Rear End Plate	1	33	1530022	Anvil Shank	1
18	0840001	Spring Pin	1	40	0850011	"O"Ring	1
19	1580002	Liner	1	41	0810013	Circlet	1
20	0840012	Spring Pin	2				
21	1530011	Rotor	1	AB-6PD-1/AB-6PDH-1(3/8)			
22	1530010	Rotor Blades	6	12	1550021	Air Strainer Assembly	1
23	0840026	Pin	1				
24	1560009	Front End Plate	1	AB-6PD-2/AB-6PDH-2(3/8)			
25	0850023	"O"Ring	1	12	1550020	Air Strainer Assembly	1
26	0860007	Bearing	1				
27	1530013	Nut	1				
28	0900001	Washer	1				
29	1530014	Cam	1				
30	1530016	Hammer Frame	1				

※We reserve the right to make changes to the designs of the parts without prior notice.